

Cybersecurity Professional Program Microsoft Security

### **DHCP**

MS-06-L1 Implementing DHCP

## Lab Objective

Understand what DHCP is used for and how it can be managed by a server.



#### **Lab Mission**

Install and configure DHCP services on a Windows server in a domain environment.



### (S) Lab Duration

30-40 minutes

# Requirements


- Basic understanding of DHCP and how to configure DHCP as a service
- Knowledge of the Windows Server environment


# **Resources**


- **Environment & Tools** 
  - VirtualBox
    - Server1 (DC) Windows Server 2016
    - Windows 7 Client


#### **Lab Task: Install and Configure DHCP**


1 Install the DHCP role on Server1. On Server1, go to **Server Manager** > **Manage** > **Add Roles and Features**, and install the DHCP Server role, as shown below.


























Complete the installation with the wizard and authorize the DHCP server by clicking Complete DHCP configuration. Click Next on the description windows and Commit on the authorization window. Make sure the credentials specified are those of the administrator.







After clicking **Commit**, the summary windows should display the status of the steps. Make sure you see *Done* for both. Close this window and the next window.




4 Open the DHCP interface by clicking **Tools** and **DHCP** and start creating a new scope by expanding **server1.cyber.com** and **IPv4**. Right-click **IPv4** and select **New Scope...** 







5 Name the scope **Cyber Scope** and click **Next**. The description is optional.




6 Set the IP address range to **10.0.0.1–10.0.0.200**, with subnet mask **255.255.255.0** and click **Next**.



**7** Exclude the range **10.0.0.1–10.0.0.10** from the DHCP allocation and click **Next**.




**8** Set the lease duration to seven days and click **Next**.



**9** When asked if you want to configure DHCP options, select **Yes...** and click **Next**.




**10** Leave the Router (Default Gateway) fields blank and click **Next**.




11 In the DNS configuration step, make sure the parent domain is *cyber.local* and add the address *10.0.0.1*, then click **Next**.


New Scope Wizard




12 Skip the configuration of the WINS server by leaving all fields blank and clicking **Next**.




13 Select the option to activate the scope now and click **Next**. In the completion window that appears, click **Finish**.



**14** Open the DHCP management tool and verify that the scope was created and activated.




- 15 Log into Client7 and configure the client to obtain an IP address.
  - Go to the client and log in as cyber\administrator.
  - Open Network and Internet Settings and go to Adapter Settings.
  - Right-click your adapter (local area connection) and click **Properties**.
  - Open TCP/IPv4 settings and change to *Obtain an IP address automatically* (do this for the DNS settings as well).




16 Open the command prompt and run the *ipconfig /all* command to determine if the DHCP server assigned an IP address to the client. *Note the physical address, or MAC address, in the green box below is* 08002752A2CD (yours may be different). You will need this when you configure the DHCP reservation in Step 19.

```
Administrator: C:\Windows\system32\cmd.exe
                                                                                     - - X
C:\Users\Administrator>ipconfig /all
                                                                                                  Ε
Windows IP Configuration
   Host Name .
   Primary Dns Suffix
                                              cuber.local
   Hybrid
                                               No
No
                                               cyber.local
Ethernet adapter Local Area Connection:
   Connection-specific DNS Suffix . : cyber.local
                                                                         Desktop Adapter
                                          .: 08-00-27-52-A2-CD
   Physical Address. .
   Autoconfiguration Enabled
Link-local IPv6 Address .
IPv4 Address . . . . . . .
                                               Yes
                                                                        2dz11(Preferred)
                                               10.0.0.11(Preferred)
255.255.255.0
   Subnet Mask . .
Lease Obtained.
                                               Thursday, November 26, 2020 9:28:23 AM
Thursday, November 26, 2020 9:28:22 AM
   Lease Expires .
   Default Gateway
   DHCP Server
DHCPv6 IAID
                                               10.0.0.1
235405351
   DHCPv6 Client DUID.
                                               00-01-00-01-27-34-25-EE-08-00-27-52-A2-CD
   DNS Servers
                                               10.0.0.1
   NetBIOS over Tcpip.
                                               Enabled
```

17 Go to the DHCP server and view address leases. In the DHCP console, go to *IPv4* > *Scope* > *Address Leases*, and view the client's lease settings.



18 Open the DHCP management tool, click your scope to expand it, and right-click *Reservations* to create a new reservation.



**19** Configure the DHCP reservations for the client with the name **For Client7**, as follows:


IP address: 10.0.0.50


MAC address: Refer to Step 16 and use your Physical/MAC address, which

may be different.

**Description: Optional** 

Support types: Select Both





20 Check the client settings to verify the reservations by requesting the IP again using *ipconfig* /*renew*. Note: If you receive an error message, try *ipconfig* instead. The system may have already assigned the reservation.

```
C:\Users\Administrator\ipconfig

Windows IP Configuration

Ethernet adapter Local Area Connection:

Connection-specific DNS Suffix .: cyber.local
Link-local IPv6 Address . . . . : fe80::79d2:39dc:be72:7e2dx11
IPv4 Address . . . . . : 10.0.0.50
Subnet Mask . . . . . . . : 255.255.255.0

Tunnel adapter isatap.cyber.local:

Media State . . . . . . . . . . . . . . Media disconnected
Connection-specific DNS Suffix .: cyber.local

C:\Users\Administrator\_
```